KWTRIO Hebelschneider 13911, Schneidelänge 385 mm (1 Stück)



Artikel-Nr. 13911 ? KWTRIO Hebelschneider 13911, Schneidelänge 385 mm ? Kauf auf Rechnung » ab Lager sofort lieferbar

Artikelnummer 13911

Gewicht 2.1kg

Produktbeschreibung

Hebelschneider KWTRIO 13911


Der **KWTRIO 13911 Hebelschneider** ist das ideale Schneidegerät für präzise und schnelle Ergebnisse sowohl im Büro als auch zu Hause. Mit seiner hochwertigen **Hartstahlklinge** sorgt er für langanhaltende Schärfe und exakte Schnitte bei verschiedenen Formaten, von A6 bis B4. Der Schneidetisch aus robustem Material und die kompakte Bauweise machen ihn besonders benutzerfreundlich und ideal für kleine Arbeitsbereiche.

Wichtige Merkmale:

- **Klingenmaterial:** Hartstahl für langanhaltende Schärfe und präzise Schnitte.
- **Schneidlänge:** 385 mm, geeignet für Formate wie A6 bis B4.
- **Sicherheitsfunktionen:** Mit einer ABS-Schutzvorrichtung, die das Verletzungsrisiko minimiert, und einem V-förmigen Messerstopp zur sicheren Arretierung der Klinge.
- **Benutzerfreundlichkeit:** Einfaches Schnellverschluss-System zur schnellen Anpassung der Schnittlängen. Ausgestattet mit einer mm- und Zoll-Skala für präzise Messungen.
- **Komfortable Bedienung:** Der Pressmechanismus sorgt für ein gleichmäßiges Klemmen des Papiers und erleichtert die Bedienung.
- **Tischgröße:** 360 x 425 mm, kompakt und perfekt für den Einsatz auf Schreibtischen oder in kleineren Arbeitsbereichen.
- **Farbe:** Grau, für eine schlichte und professionelle Optik.

Der **KWTRIO 13911 Hebelschneider** ist die perfekte Wahl für alle, die Wert auf Präzision und Sicherheit legen. Egal ob für das Schneiden von größeren Formaten oder feinen, kleineren Schnitten – dieses Gerät bietet stets exzellente Ergebnisse.

Weitere Bilder


BEFORE USING THIS PRODUCT, READ, UNDERSTAND, AND FOLLOW THESE INSTRUCTIONS.

FOR INDOOR USE ONLY

IMPORTANT SAFEGUARDS

- Read all instructions before using.
- This product is not intended for use by children. Keep product out of the reach of children and pets.
- This product is intended for use to trimming paper. Do not use the product for any other purpose.
- Keep loose items (e.g., hands, fingers, jewelry, clothing, sandcloths, etc.) away from the blade to avoid personal injury or damage to the product.
- ⚠ To avoid damage to the product:
  - Remove staples and paper clips from items before trimming paper.
  - Never lubricate the cutting blade.
  - Do not expose product to water or other liquids.
- ⚠ To avoid possible severe personal injury:
  - Never operate the it trimmer w/Hand; the safety shield to place
  - Never leave the blade unlocked.
  - Never carry the it trimmer by the cutting handle.
  - Always ensure the blade lock is secure when the product is not in use.
- Do not attempt to dislodge jammed debris with a pointed object, as personal injury or product damage may occur.
- Do not use the product on a wet, slippery, or unstable surface.
- Do not hang or wall mount the product.
- This product is intended for indoor use only. Do not use outdoors.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

Components description

Blade

Paper guide

Safety shield

Blade lock

Performance

Specification	A4	B4	A3
Cutting length(mm)	385	385	385
Cutting thickness	0.1	0.1	0.1
Cutting capacity (sheet/80 gsm)	10	10	10
Blade	SK5 steel	SK5 steel	SK5 steel
Cutting mode	Lever	Lever	Lever
Base	Metal	Metal	Metal
Measuring scale	Metric	Metric	Metric
Overall dimension	39.5*8	47.5*8	59*8

How to use

1.Set the handle and blade to the desired starting position.

2.Move up the handle to open the blade slowly.

3.Align the paper to the desired position.

4.Pull down the handle to cut the paper slowly and evenly.

5.Try handed three cutting, the handle and blade will return to the original handle and blade.

6.Turn on the safety cap and put the handle back to the "lock" position, then the tool is in use.